

Toy	Description	Function	C	R&S	EHC	FM	VS	AS	TS	C&E	SC	M	?	Mob	GM	SD	SS
UFO Starship-2 (ED)	grey circular spaceship with buttons on bottom	lights up and makes spaceship sounds when pushed down					x	x									
Hearing Impaired Activity Center-1 (ED)	red base with red and yellow buttons and wooden toggle pull	vibrates, lights up, and activates fan when buttons are pushed or toggle is pulled				x	x		x								
Hearing Impaired Activity Center-2 (ED)	red base with red and yellow buttons and wooden toggle pull	vibrates, lights up, and activates fan when buttons are pushed or toggle is pulled				x	x		x								
Vibrating Light (ED)	blue platform with large yellow light button in center	platform vibrates and light lights up when button is pushed					x		x								
Pony Pal (ED)	black pony	pony moves when activated by a switch		x			x										
Skipping Dog (ED)	tan and brown puppy	puppy skips when activated by switch		x			x										
Highrise Rescue (ED)	pieces for a ladder with a base and fireman	construct a ladder and use the switch to make the fireman climb to the top					x			x							
Kaleido-dome (ED)- BROKEN	blue platform with rainbow sections along border and dome full of rainbow balls in center	lights flash and balls bounce when button is pushed					x			x							
Go Go School Bus (ED)	school bus with remote on velcro stand	bus drives around when activated by the remote on the velcro stand					x							x			
Bead Chain with Music (ED)	blue platform with hanging beaded curtain fixed to it	music plays when beaded curtain is moved						x	x	x							

Toy	Description	Function	C	R&S	EHC	FM	VS	AS	TS	C&E	SC	M	?	Mob	GM	SD	SS
Tickle Me Ernie	Ernie from Sesame Street	Ernie laughs and vibrates when activated by a switch						x	x								
Ring Around Bells (ED)	blue base with rotating colorful bells	bells spin around when activated by switch				x		x		x							
Parts of a Whole Game (ED)	blue platforms with 4 mazes that form 4 different shapes when completed	when the correct pieces are matched the recorded sound plays				x		x			x		x				
Dora Talker with stand	blue stand with yellow star with Dora the Explorer on it	buttons make sound as they are pushed				x		x									
Story Teller (ED)	blue platform with yellow bumpy button and rotating circle	repeats phrases when button is pushed	x					x									
Lighted Musical Plate Switch (ED)	blue slanted platform with large rectangular yellow button	when button is pushed, music sounds and toy is activated						x		x							
Rainbow Worm	4 piece worm that makes noise when assembled	child puts ends of pieces together and assembled worm lights up and makes noise						x		x							
UFO Busy Box- 1 (ED)	silver circular platform with 5 multi colored buttons	when buttons are pushed, different UFO noises sound						x		x							
UFO Busy Box- 2 (ED)	silver circular platform with 5 multi colored buttons	when buttons are pushed, different UFO noises sound						x		x							

Toy	Description	Function	C	R&S	EHC	FM	VS	AS	TS	C&E	SC	M	?	Mob	GM	SD	SS
Speech Therapist (ED)	blue platform with yellow button and place to secure a mirror	when button is pushed recorded sound is played- up to four 5 second phrases can be recorded	X														
Talk 4&8 Icon CD #2505 (ED)	cd	creates icons for communication devices	X														
Talk 8 with levels-1 (ED)	silver platform with 8 square buttons	when buttons are pushed recorded sound is played	X														
Talk 8 with levels-2 (ED)	silver platform with 8 square buttons	when buttons are pushed recorded sound is played	X														
Vertical Wobble Switch-1 (ED)	yellow platform with joystick switch	when joystick is moved the toy that the switch is plugged in to is activated		x						x							
Vertical Wobble Switch-2 (ED)	yellow platform with joystick switch	when joystick is moved the toy that the switch is plugged in to is activated		x						x							
Wobble Switch with Arm-1 (ED)	moveable arm on platform with joystick switch	when joystick is moved the toy that the switch is plugged in to is activated		x						x							
Wobble Switch with Arm-2 (ED)	moveable arm on platform with joystick switch	when joystick is moved the toy that the switch is plugged in to is activated		x						x							
Animals	various animals standing on 4 legs	when activated animals move and make sound		x													
Butterfly two piece puzzle	wooden butterfly puzzle	fit two pieces together to make butterfly			x						x						
Caterpillar 3 piece puzzle	wooden caterpillar puzzle	fit three pieces together to make caterpillar			x						x						
Flower two piece puzzle	wooden flower puzzle	fit two pieces together to make flower			x						x						
Puzzlers	9 picture cubes that assemble into pictures	child manipulates the blocks to assemble pictures			x						x						

Toy	Description	Function	C	R&S	EHC	FM	VS	AS	TS	C&E	SC	M	?	Mob	GM	SD	SS
Rainbows, Rabbits, and Roses	alpha floor puzzle	large floor puzzle of the alphabet with pictures that start with each letter			x						x						
Big Red Button	Grey platform with big red button	when button is pushed toy that is plugged in is activated								x							
BIGmack- BLACK	black platform with big red button	when button is pushed recorded sound is played or toy is activated								x							
BIGmack- BLUE	black platform with big red button	when button is pushed recorded sound is played or toy is activated								x							
BIGmack- RED	black platform with big red button	when button is pushed recorded sound is played or toy is activated								x							
BIGmack- YELLOW	black platform with big red button	when button is pushed recorded sound is played or toy is activated								x							
CD Case Switch	yellow CD case with a "press here" insert	when button is pushed toy that is plugged in is activated								x							
Dis Turtle Switch (ED)	green turtle with button on bottom	when turtle is pushed down button is pushed and toy is activated								x							
Grip Puff Switch (ED)	white platform with interchangeable puffy grips of various colors and sizes	when grip is squeezed toy that is plugged in is activated								x							
Large input orange switch (ED)	orange switch that plugs into a toy with a large input end	push the orange button and the toy plugged in is activated								x							
Medium Brown Button	tan platform with medium brown button	when button is pushed toy that is plugged in is activated								x							

Toy	Description	Function	C	R&S	EHC	FM	VS	AS	TS	C&E	SC	M	?	Mob	GM	SD	SS
Medium Purple Button	black platform with medium purple button	when button is pushed toy that is plugged in is activated								x							
Small Yellow Button	black platform with small yellow button	when button is pushed toy that is plugged in is activated								x							
Rubber ball	red rubber ball	feel the texture of the ball and bounce it												x	x		
Slant Board- 1 (ED)	blue slanted clip board	clip paper in clip and use to write on													x		
Slant Board- 2 (ED)	blue slanted clip board	clip paper in clip and use to write on													x		
Slant Board- 3 (ED)	blue slanted clip board	clip paper in clip and use to write on													x		

Key
C-COMMUNICATION
R&S-REACH AND SWIPE
EHC-EYE HAND COORDINATION
FM-FINE MOTOR
VS-VISUAL STIMULATION
AS- AUDITORY STIMULATION
TS- TACTILE STIMULATION
C&E- CAUSE AND EFFECT
SC-SPATIAL CONCEPTS
M-MEMORY
?-THINKING
Mob-MOBILITY
GM-GROSS MOTOR
SD-SIZE DISCRIMINATION
SS-SOMATOSENSORY STIMULATION
M-MEMORY
?-THINKING

Mob-MOBILITY
GM-GROSS MOTOR
SD-SIZE DISCRIMINATION
SS-SOMATOSENSORY STIMULATION